

0x17e

B6.2-3 gear stick 0: Park / 1: Reverse / 2: Neutral / 3: Drive

0x186

B5 & B6.0-1 power pedal [0,1000]

0x18a

B2 & B3.0-1 Power pedal [0,800]

B3.3 power pedal (push further) 0: not engaged / 1: engaged

0x1f6

B2.4 break pedal 0: released / 1: pressed

0x352

B3 break pedal force

0x42e

B5.0-3 ?? 15: when 3 phases connected, 0: when disconnected

B7 ?? decreases while charging

?? indicates 0 when charging is done (jumped from 0 to 4)

?? maybe this is the power that is taken from the line?

0x4f8

B0.4 hand break 0: released / 1: put on

B0.5 hand break 0: put on / 1: released

0x5de

B0.1 right direction indicator 0: off / 1: on

B0.2 left direction indicator 0: off / 1: on

B0.3-4 ??

B0.5 parking light 0: off / 1: on

B0.6 beam light 0: off / 1: on

B0.7 high beam light 0: off / 1: on

B1.0-3 ??

B1.4 left front door 0: close / 1: open

B1.5 ??

B1.6 right front door 0: close / 1: open

B1.7	??	
B2.0	??	
B2.1	left rear door	0: close / 1: open
B2.3	right rear door	0: close / 1: open
B2.4-7	??	
B3-6	??	
B7.0-2	??	
B7.3	back door	0: close / 1: open
B7.4-7	??	

0x5ee

B0.0	parking light	0: off / 1: on
B0.1	beam light	0: off / 1: on
B0.2	high beam light	0: off / 1: on
B3.3	driver door	0: close / 1: open

0x646

B0	??	
B1	10x average trip B consumption (kWh/100km)	
B2-3 & B4.0	10x trip B distance (km)	
B4.1-7 & B5	10x trip B total consumption (kWh)	
B6 & B7.0-3	10x average trip B speed (km/h)	
B7.4-7	-- unused --	

0x652

B0	?? increases while charging	
	?? 196 when finished	
B2.5-7 & B3.0-6	?? trip A distance (km)	
B4.5-7 & B5	?? trip total consumption (kWh)	

0x653

B1.1	driver seat belt	0: fastened / 1: released
------	------------------	---------------------------

0x654

B4	% of battery	[0,100]
B5 & B6.0-1	remaining charge time in minutes	1023: --:--
B6.2-7 & B7.0-3	remaining km	

0x65b

B4.1-2	ECO mode	0: off / 1: on
B5.1-2	battery flap	0: closed / 1: open & connected / 2: open & disconnected

0x66a

B0.5-7	000: cruise control & speed limiter off 001: speed limiter on, active 010: speed limiter on, not active 101: cruise control on, not active
B1	speed control max speed [30,200] / 254: off

0x68b

B0.0-3	increases each time as button on the media control (right of the steering wheel), on the R-Link screen or control or one of the following is pressed: - voice control
--------	--

0x68c

B2.7 & B3	?? increases while charging max 268 ?? also increases after 99% when calibrating batteries ?? increases also after the charge
-----------	---

0x699

B0.0-1	??
B0.2-3	rear window defroster 1: on / 2: off
B0.4-6	windscreen defroster 3: on / 4: off
B0.7	??
B1.0-1	??
B1.2-6	preferred temperature [18,26] / 4: min / 5: max
B1.7	??
B2.0	air distribution top
B2.1	??
B2.2	air distribution middle
B2.3	air distribution bottom
B2.4-5	air recycling 1: on / 2: off
B2.6-7	ECO mode 0: off / 1: on
B3.0-3	fan level [1,8] / 15: off / 0: windscreen defroster or automatic temperature

B3-4-7	??	
B4-5	??	
B6.0-3	??	
B6.4-5	automatic temperature	1: off / 2: off
B6.6-7	air conditioning	0: fan off / 1: on / 2: off
B7.0	fan	0: off / 1: on
B7.1-7	??	